









# //metro m10 assembly instructions



**Duration:**  
30 - 45 mins

**How many:**  
One person

**Tools you'll need: (power driver is optional)**

 2mm	 3mm	 4mm	 5mm
 PH 2	 PZ 2		

2mm hex key   3mm hex key   4mm hex key   5mm hex key  
PH 2 screwdriver   PZ 2 screwdriver   Power driver

Recommended torque setting for expanding profile locks is 2 - 2.5 Nm

**Before you begin:**  
Please familiarise yourself with the Unibox icons



**1** Lower the elliptical post onto the foot plate. Tighten grub screws to secure.



**2** Fit 600mm 2-way beam between posts. Tighten the profile locks at both ends.



**3** Lower back panel down both side channels until it rests in the lower channel.



**4** Fit 600mm 2-way beam.




**5** Tighten profile locks at both ends.



**6** Fit 150mm 1-way beams with profile lock hex sockets facing inwards. Top of beam should be 100mm from top of foot.



**7** Offer the front elliptical post to the lower 1-way beam.



**8** Tighten profile locks.



**9** Offer the panel profile to the elliptical post channels.





